

INSTALLATION AND SAFETY INSTRUCTIONS


INSTALLATION INSTRUCTIONS HC-255

Snaps onto any point along 9435 or 9443 track to secure to surface.

Use supplied wood screw when installing to a wood surface.

Use wall anchor (not included) when installing to drywall or other hollow surfaces.

Space clips according to weight of fixtures, not allowing track to sag.



112195

INSTALLATION AND SAFETY INSTRUCTIONS


INSTALLATION INSTRUCTIONS HC-255

Snaps onto any point along 9435 or 9443 track to secure to surface.

Use supplied wood screw when installing to a wood surface.

Use wall anchor (not included) when installing to drywall or other hollow surfaces.

Space clips according to weight of fixtures, not allowing track to sag.



112195

INSTALLATION AND SAFETY INSTRUCTIONS


INSTALLATION INSTRUCTIONS HC-255

Snaps onto any point along 9435 or 9443 track to secure to surface.

Use supplied wood screw when installing to a wood surface.

Use wall anchor (not included) when installing to drywall or other hollow surfaces.

Space clips according to weight of fixtures, not allowing track to sag.



112195

INSTALLATION AND SAFETY INSTRUCTIONS


INSTALLATION INSTRUCTIONS HC-255

Snaps onto any point along 9435 or 9443 track to secure to surface.

Use supplied wood screw when installing to a wood surface.

Use wall anchor (not included) when installing to drywall or other hollow surfaces.

Space clips according to weight of fixtures, not allowing track to sag.



112195