


Motion Sensor Switch

Part Number	Description and Use	Dimensions
T-MSS-60W	Motion sensor switch. Mount sensor switch as close as possible to where movement will occur – facing out. Use with single color tape light or puck lights.	1/2" x 2-1/4"



1. Insert Male Plug on Power Supply into Female Plug on Motion Sensor. Insert Male Plug on Motion Sensor into Female Connector on lights.

2. Use adhesive pad to hold switch to mounting surface; complete installation by securing with enclosed screws.

3. Use in lazy susan or pantry cabinet - lights turn on when door is open, and movement is detected.

